



(« ») FreeSpeech™

MP-FS-LANYARD



Use this light-weight, adjustable neck strap to wear an MP-FSMIC FreeSpeech™ Wireless Microphone comfortably around the neck. Assemble to the MP-FSMIC as illustrated on the reverse side.

WARNING: The lanyard poses a possible strangulation hazard. Do not leave the lanyard, or the MP-FSMIC with lanyard attached, unattended in any area where children or pets may be present.



Crestron Electronics, Inc.
15 Volvo Drive, Rockleigh, NJ 07647
Tel: 888.CRESTRON Fax: 201.767.7576
www.crestron.com

DOC. 7201A
(2030981)
05.11



- Attach the lanyard to the MP-FSMIC microphone as shown below:
1. Detach the magnet from the mount plate.
 2. Place the adjustable slider over the mount plate, and secure with the magnet.
 3. Use the lanyard breakaway connectors to secure the lanyard around the neck.
 4. Hold the bottom of the lanyard and slide the mic up or down to a comfortable position.

